

DEPARTURE ROUTE DESCRIPTION

(Continued)

HOBOZ TRANSITION (NQI2 • HOBOZ):

Rwys 13L/R and 35L/R: Turn left to join and arc NE on the NQI 7 DME arc to join and fly NQI R-339 to HOBOZ.

Rwys 17L/R and 31L/R: Turn right to join and arc W on the NQI 7 DME arc to join and fly NQI R-339 to HOBOZ.

JUBAK TRANSITION (NQI2 • JUBAK): *

Rwys 13L/R and 17L/R: Turn left to join and arc SE on the NQI 7 DME arc to join and fly NQI R-125 to JUBAK.

Rwys 31L/R and 35L/R: Turn right to join and arc NE on the NQI 7 DME arc to join and fly NQI R-125 to JUBAK.

RICTO TRANSITION (NQI2 • RICTO): *

Rwys 13L/R and 17L/R: Turn right to join and arc S on the NQI 7 DME arc to join and fly NQI R-225 to RICTO.

Rwys 31L/R and 35L/R: Turn left to join and arc W on the NQI 7 DME arc to join and fly NQI R-225 to RICTO.

* RICTO and JUBAK transitions are for local use for Special Use Airspace entry only.

LOST COMMUNICATIONS: If no transmissions are received one minute after departure, climb to assigned altitude, proceed direct assigned navaid or intercept NQI TACAN 7 DME arc, arc to respective departure radial then via departure radial to assigned departure fix. Then via assigned transition or route. Once established on departure radial climb to filed altitude.