
AIRPORT DIAGRAM
17117
MIAMI INTL (MIA)
MIAMI, FLORIDA
FIELD ELEV 9
CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.
D-ATIS
ARR 119.15
DEP 133.675
MIAMI TOWER
118.3 256.9
123.9 (090-269)
GND CON
121.8 348.6
(RWY 08L, 08R, 12, 26L, 26R)
127.5 348.6
(RWY 09, 27, 30)
CLNC DEL
135.35
CPDLC
D
VAR 6.4° W
JANUARY 2015
ANNUAL RATE OF CHANGE
0.1° W
80°18'W
80°17'W
80°16'W
25°48'N
25°47'N
Landing 30
Holdbar for 26L
Clearance
Hold
here for
08R & 12
Landing 26L
Holdbar for
30 Clearance
Corral Area
UPS
FED EX
FBO
CUSTOMS
&
GAC
NORTHSIDE
FIRE
STATION
808
RAMP
NORTHEAST
BASE
CENTRAL
BASE
ELEV 8
093.8°
8600 X 150
10506 X 200
273.8°
HS 1
HS 2
HS 3
HS 4
HS 5
SEE INSET
MIDFIELD
FIRE
STATION
PENALTY
BOX
TWR
341
125.9°
9355 X 150
MIDFIELD
BLAST FENCE
305.9°
WEST CARGO BASE
EASTERN U
WESTERN
U
BCN
LAHSO
ELEV 7
13016 X 150
RWY 08L-26R
PCN 70 F/A/X/T
S-130, D-210, 2D-420, 2D/2D2-850
RWY 08R-26L
PCN 70 F/A/X/T
S-130, D-210, 2S-175, 2D-420, 2D/2D2-850
RWY 09-27
PCN 70 F/A/X/T
S-130, D-210, 2S-175,
2D-420, 2D/2D2-850
RWY 12-30
PCN 70 F/A/X/T
S-130, D-210, 2S-175,
2D-420, 2D/2D2-850
ASDE-X in use. Operate transponders
with altitude reporting mode and ADS-B
(if equipped) enabled on all airport surfaces.
AL-257 (FAA)